



#### FANP /BATTERY ROOM

##### FEEDER:

3\*4mm2Ø1" XLPE

CONNECTED LOAD \*\*\*KW

NOTE:1- SPU'S ARE ALT

ERNATING EACH 12HRS BY 24H TIMER

2- ROOM THERMOSTAT TO CONTROL ROOM TEMPERATURE, IF ANY FAN'S FAIL TO START, TEMP. INCREASE THERMOSTAT ACTIVATES THE RELAY WHICH IN TURN BY-PASS THE TIMER AND OPERATES THE TWO UNITS.

3- SOUNDER WILL BE ON.

4- FAN'S ARE AUTO START.