

ACP/BATTERY ROOM
FEEDER:
3*6mm2Ø1" XLPE
CONNECTED LOAD ***KW
NOTE:1- SPU'S ARE ALT
ERNATING EACH 12HRS BY 24H TIMER
2- ROOM THERMOSTAT TO CONTROL ROOM TEMPERATURE, IF
ANY SPU'S FAIL TO START, TEMP. INCREASE THERMOSTAT
ACTIVATES THE RELAY WHICH IN TURN BY-PASS THE TIMER
AND OPERATES THE TWO UNITS.
3- SOUNDER WILL BE ON.
4- SPU'S ARE AUTO START.